

How to get started with your BT 1560 from Cypher Lab

Your Scanner comes with two parts (a scanner and a cradle) and two cables to connect the cradle (a) to the computer and (b) to the power.

To connect the power to the cradle

1. Turn the cradle over and look in the bottom of the cradle



2. Now connect the computer cable to your computer and turn the cradle on.
3. Your computer should automatically recognise that this device is connected. You should see a small message at the bottom of your screen saying "USB Human Interface Device Installed"
4. When using your barcode for the first time, remember – it is waking up – hold in the scanner trigger for 3 – 5 seconds until it beeps. Then wait for the scanner indicator light to show a red bar of light
5. Now, turn over the base unit, there are two small barcodes on the bottom of the unit

6. Scan the “set connection” barcode first, this is the top barcode
7. Now scan the serial # barcode below it
8. Now on your cradle you should see a rapidly flashing blue light
9. Open a notepad document on your computer and click anywhere within the notepad document. Scan a barcode from anything you have around you, the barcode number should appear in the notepad document you just opened.
10. Now the scanner should have a standard flashing blue light.
11. When you put the scanner back into the cradle, the light should turn red, as it is now charging.